


Hinge system Snap On

Installation jigs



Twist Lock Connector Cup and varnish protection piece




Connector Cup 4000 U	18839-41
Connector Cup 4000 L	18937-41

PU 50 pcs.

Baseplate fixing bracket, Snap On 3000 system


The fixing bracket is used to position and to screw on baseplates (straight and wing versions).



W 3000 univ. space 0.5	90890
W 3000 univ. space 2.0	20278

Marking guide for baseplates, Snap On 3000 system

Used to predrill hole pattern with pilot drill



Marking guide, nickel-plated

Space 0.5	31264
Space 2.0	15254

Insertion die Snap On 3000

Use only with predrilled hole patterns (32 mm system). Place the marking guide on the line boring holes and mark the position of hinge (only when using wing baseplates)



Insertion die	38207
---------------	-------